



HAVING TROUBLE LIGHTING THE BBQ OR THE FLAMES LOW? **HERE IS HOW TO FIX IT!**

All BBQs come equipped with a low flow regulator which is designed to reduce pressure if it detects a leak. Unfortunately, the safety feature can be easily tricked into thinking there is a leak. When this happens you will have difficulty lighting the grill and experience low flames that generate low heat.

To avoid this or to reset the regulator, follow these steps

- Make sure all burners are in OFF position
- Turn off the propane tank valve
- Disconnect the hose from the tank
- Wait at least 15 seconds to reconnect the hose
- Turn ON the propane tank valve **SLOWLY**. DO NOT turn the burner valves to the 'on' position first.
- With the tank valve in the OPEN position turn the red pilot knob to the ON position and light the pilot.
- Turn on all the burners when the pilot is lit.
- Make sure to turn OFF all the burner valves and pilot light **BEFORE** turning off the tank valve.

Failure to turn off the BBQ the correct way will cause the regulator to falsely detect a leak and cause problems the next time the grill is used.